



INSTALLATION:

Stand grate on end. Slide the Beaver Dam Bag on with Dam on top of the grate. Pull all excess down. Lay unit on its side. Carefully tuck flap in. Press Velcro strips together. Install the unit making sure front edge of grate is inserted in frame first then lower back into place. Press Velcro dots together which are located under lifting straps. This ensures straps remain flush with gutter.

MAINTENANCE:

With a stiff bristle broom sweep silt and other debris off surface after each event.

<p>Approved By:</p>  <p>City Engineer, EMH&T Inc</p>  <p>City Service Director</p>	<p>STANDARD DIMENSIONS FOR</p> <p>THE BEAVER DAM OR EQUIVALENT</p>	<p>CITY OF GROVE CITY, OHIO</p>	
<p>STANDARD CONSTRUCTION DRAWING</p>		<p>Revised October 2015</p>	<p>Drawing No. C-GC-72A</p>